


cosori®

Electric Glass Kettle



User Manual

Bring warmth to your day.

From freshly brewed tea to steaming instant noodles,
your new kettle brings cozy comfort to every moment.

Table of Contents

Package Contents	3
Specifications	3
Important Safeguards	4
Getting to Know Your Glass Kettle	7
Before First Use	8
Using Your Glass Kettle	9
Limited Warranty Information	12
Customer Support	14

Package Contents

- 1 × Electric Glass Kettle
- 1 × Power Base
- 1 × User Manual

Specifications

Model	CGK-G173-KUS, CGK-G173-WUS, CGK-G173-GUS
Power Supply	AC 120V, 60Hz
Rated Power	1,500W
Capacity	7 US cups / 1.7 L
Dimensions	10.3 x 8.7 x 5.9 in / 26 x 22 x 15 cm
Weight	2.7 lb / 1.2 kg

READ AND SAVE THESE INSTRUCTIONS

Important Safeguards

Follow basic safety precautions when using your kettle. Read all instructions.



CAUTION!

- **Do not** touch hot surfaces. Use handle and buttons. **Do not** touch the base or glass parts of the kettle during or immediately after operation.
- **Do not** fill the kettle above the "MAX" line. This may cause water to boil over and may cause scalding.
- **Always** handle with care when there is hot water inside the kettle to avoid scalding.
- **Do not** immerse the kettle, base, cord, or plug in water or other liquids.
- Closely supervise children near the kettle. **Do not** allow children to use or play with the kettle.
- Unplug the kettle when it is not being used and before cleaning. This will avoid electric shock and prevent moisture from causing a short circuit in the power base while it is plugged in.
- Allow to cool before putting on or taking off parts, and before cleaning.
- **Do not** use the kettle if it is malfunctioning, broken or chipped, or if the power cord or plug is damaged in any way. **Do not** try to repair the kettle. Contact **Customer Support** (see page 14).
- Use caution when refilling or moving the kettle while it is still hot.
- While water is boiling, or just after water has been boiled, avoid contact with the steam from the spout.
- Using accessory attachments not recommended by the manufacturer may result in fire, electric shock, or injury.
- **Do not** use outdoors.
- Place the kettle on a dry, flat surface. **Do not** place the kettle on or near heat sources such as stovetops, ovens, radiators, etc.
- **Always** make sure the lid is closed while the kettle is operating. **Do not** cover the spout opening while the kettle is operating. **Do not** cover the slits near the **On/Off Switch**.



WARNING: Avoid spilling liquid on the electrical connector and power base.

WARNING: Heated surfaces are subject to residual heat after use.

- To disconnect, use the **On/Off Switch** to turn the kettle off, then remove the plug from the wall outlet.
- **Only** use the kettle as directed in this manual.
- Scalding may occur if the lid is removed during the brewing cycles.
- The appliance is only used with the stand (Power Base) provided.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the kettle by a person responsible for their safety.
- Children should be supervised to ensure that they **do not** play with the kettle.
- Cleaning and user maintenance shall not be done by children without supervision.
- See **Care & Maintenance** (page 10) for guidelines on how to clean the kettle.
- Household use **only**.
- **Do not** leave your kettle unattended while in use.

PLUG & CORD

- **Do not** let the cord (or any extension cord) hang over the edge of a table or counter. **Do not** allow the cord to touch hot surfaces.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.
- Your kettle should only be used with 120V, 60Hz electrical systems. **Do not** plug into another type of outlet.
- Keep the kettle and its cord out of reach of children.
- To unplug, grab the plug and pull from the outlet. Never pull from the power cord.
- **Never** use an outlet below the counter when plugging in your kettle.
- A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- If the power-supply cord is damaged, it must be replaced by Arovast or similarly qualified persons in order to avoid an electric or fire hazard. Please contact **Customer Support** (page 14).


EXTENSION CORDS

- Longer extension cords are available and may be used if care is exercised in their use. If a longer extension cord is used:
 - The marked electrical rating of the extension cord should be at least as great as the electrical rating of the kettle.
 - The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

WARNING: Any other servicing should be performed by an authorized service representative.

SAVE THESE INSTRUCTIONS

Getting to Know Your Glass Kettle



Note: The filter is made with food-grade 304 stainless steel

Before First Use

Test Run



CAUTION!

If your glass kettle is broken, **do not** remove it from the packaging. Contact **Customer Support** immediately to replace your kettle (see page 14).

Perform a test run before using your kettle to make sure it's working properly. **Do not** drink the water that is boiled during this test.

1. Remove all packaging from your kettle and its accessories, including any temporary stickers.
2. Completely unravel the power cable and place the power base on a flat, level surface.
3. Press the **Lid Release Button** to open the lid. *[Figure 1.1]*




Figure 1.1

4. Fill the kettle with water to the “MAX” line, then close the lid. *[Figure 1.2]* Place the kettle on the power base and plug in.



Figure 1.2

5. Press the **On/Off Switch**. The blue indicator light will turn on. *[Figure 1.3]*




Figure 1.3

6. The kettle will automatically turn off once it has finished boiling the water. Allow it to cool for at least 5 minutes, then pour out the water.

Using Your Glass Kettle

Boiling Water

This kettle should **only** be used for boiling water. **Do not** boil other liquids in this kettle.

1. Press the **Lid Release Button** to open the lid.
2. Fill the kettle to the desired level. **Do not** fill above the “MAX” line. [Figure 2.1]



Figure 2.1

3. Close the lid and place the kettle onto the power base and plug in. [Figure 2.2]




Figure 2.2

4. Press the **On/Off Switch**. The blue indicator light will turn on. [Figure 2.3]




Figure 2.3

5. The kettle will automatically turn off once it has finished boiling the water.

Note:

- **Always** fill the kettle with water to at least the “MIN” line to prevent overheating.
- You can stop the heating process by flipping the **On/Off Switch** up at any time.
- This kettle has a boil dry safety feature. If there is no water inside the kettle, it will automatically turn off to prevent the heating plate from overheating.
- If the kettle overheats, fill it with cold water and wait for 2 minutes before using again.

Care & Maintenance

Note: **Do not** remove the filter from the lid. Doing so will break the filter.

Cleaning

1. Unplug the kettle and allow it to cool before cleaning.
2. Wipe the kettle and base with a soft, damp cloth. Make sure that the electric socket on the underside of the kettle is kept dry.
3. Dry all parts after every use.

Note: **Never** immerse kettle or power base in water.

Descaling the Kettle

We recommend descaling the kettle at least once a week if used frequently. Descaling removes any mineral deposits that have built up inside the kettle.

Always descale the kettle before and after storing for long periods of time.

1. Unplug the kettle and pour out any remaining water. Make sure the kettle is cool.
2. Choose one of the following mixtures and add to the kettle: *[Figure 3.1]*



Figure 3.1

- 1 part vinegar to 1 part water
- 3 US tbsp / 50 mL of lemon juice and 2 US cups / 500 mL of water
- 1 tsp / 5 mL of baking soda and 2 US cups / 500 mL of water

3. Turn on the kettle and boil the mixture.
4. Let the mixture sit for 15–30 minutes. For stubborn buildup, let the mixture sit for longer.
5. Pour out the cooled mixture and use a non-scratch sponge or soft cloth to wipe away any remaining scale. *[Figure 3.2]*



Figure 3.2

Note: **Do not** use steel wool, as this can scratch the kettle

6. Fill the kettle with clean water and boil it.
7. Pour out the water. Rinse with clean water until there is no remaining smell. *[Figure 3.3]*




Figure 3.3

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC SDOC SUPPLIER'S DECLARATION OF CONFORMITY

Arovast Corporation hereby declares that this equipment is in compliance with FCC requirements.

The declaration of conformity can be found at: <https://www.vesync.com/legal/compliance/fcc>

Limited Warranty Information

Product Name	Electric Glass Kettle
Model	CGK-G173-KUS, CGK-G173-WUS, CGK-G173-GUS
<i>For your own reference, we strongly recommend that you record your order ID and date of purchase.</i>	
Order ID	
Date of Purchase	

Cosori Limited Product Warranty

Register your products at <https://warranty.cosori.com/warranty> to stay up to date with important product information such as product updates, limited warranties, usage and maintenance recommendations, and notifications concerning safety warnings or product recalls. Registration is not required to claim your limited warranty.

Two (2) Year Limited Consumer Product Warranty

Arovast Corporation ("Arovast") warrants that the product shall be free from defects in material and workmanship for a period of **2 years from the date of original purchase** ("Limited Warranty Period"), provided the product was used in accordance with its use and care instructions (e.g. in the intended environment and under normal circumstances).

California Residents Only

The Warranty Period begins on the original date of delivery or pick-up.

Your Limited Warranty Benefits

During the Limited Warranty Period and subject to this limited Warranty Policy, Arovast will, in its sole and exclusive discretion, either (i) refund the purchase price if the purchase was made directly from the online Cosori store, (ii) repair any defects in material or workmanship,

(iii) replace the product with another product of equal or greater value, or (iv) provide store credit in the amount of the purchase price.

Who Is Covered?

This limited warranty extends only to the original consumer purchaser of the product and is not transferable to any subsequent owner of the product, regardless of whether the product transferred ownership during the specified term of the limited warranty. The original consumer purchaser must provide verification of the defect or malfunction and proof of the date of purchase to claim the Limited Warranty Benefits.

Be Aware of Unauthorized Dealers or Sellers

This limited warranty does not extend to products purchased from unauthorized dealers or sellers. Arovast's limited warranty only extends to products purchased from authorized dealers or sellers that are subject to Arovast's quality controls and have agreed to follow its quality controls. Please be aware, products purchased from an unauthorized website or dealer may be counterfeit, used, defective, or may not be designed for use in your country. You can protect yourself and your products by making sure you only purchase from Arovast or its authorized dealers.

If you have any questions about a specific seller, or if you think you may have purchased your product from an unauthorized seller, please contact our Customer Support via support.cosori.com.

What's Not Covered?

- Normal wear and tear, including parts that might wear out over time (e.g. batteries, filters, cleaning brush, essential oil pads, etc.).
- If the proof-of-purchase has been altered in any way or is made illegible.
- If the model number, serial number or production date code on the product has been altered, removed or made illegible.
- If the product has been modified from its original condition.
- If the product has not been used in accordance with directions and instructions in the user manual.

- Damages caused by connecting peripherals, additional equipment or accessories other than those recommended in the user manual.
- Damages or defects caused by accident, abuse, misuse, or improper or inadequate maintenance.
- Damages or defects caused by service or repair of the product performed by an unauthorized service provider or by anyone other than Arovast.
- Damages or defects occurring during commercial use, rental use, or any use for which the product is not intended.
- If the unit has been damaged, including but not limited to damage by animals, lightning, abnormal voltage, fire, natural disaster, transportation, dishwasher, or water (unless the user manual expressly states that the product is dishwasher-safe).
- Incidental and consequential damages.
- Damages or defects exceeding the cost of the product.

Claiming Your Limited Warranty Service in 5 Simple Steps:

1. Make sure your product is within the specified limited warranty period.
2. Make sure you have a copy of the invoice and order ID or proof-of-purchase.
3. Make sure you have your product. **DO NOT** dispose of your product before contacting us.
4. Contact our Customer Support team via support.cosori.com.
5. Once our Customer Support team has approved your request, please return the product with a copy of the invoice and order ID.

Sole and Exclusive Remedy

THE FOREGOING LIMITED WARRANTY CONSTITUTES AROVAST CORPORATION'S EXCLUSIVE LIABILITY, AND YOUR SOLE AND EXCLUSIVE REMEDY, FOR ANY BREACH OF ANY WARRANTY OR OTHER NONCONFORMITY OF THE PRODUCT COVERED BY THIS LIMITED PRODUCT WARRANTY STATEMENT. THIS

LIMITED WARRANTY IS EXCLUSIVE, AND IN LIEU OF ALL OTHER WARRANTIES. NO EMPLOYEE OF AROVAST CORPORATION OR ANY OTHER PARTY IS AUTHORIZED TO MAKE ANY WARRANTY IN ADDITION TO THE LIMITED WARRANTY IN THIS LIMITED PRODUCT WARRANTY STATEMENT.

Disclaimer of Limited Warranties

TO THE FULLEST EXTENT PROVIDED BY APPLICABLE LAW, EXCEPT AS WARRANTED IN THIS LIMITED PRODUCT WARRANTY POLICY, AROVAST CORPORATION PROVIDES THE PRODUCTS YOU PURCHASE FROM AROVAST CORPORATION "AS IS" AND AROVAST CORPORATION HEREBY DISCLAIMS ALL WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, STATUTORY, OR OTHERWISE, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, AND FITNESS FOR PARTICULAR PURPOSE.

Limitations of Liability

TO THE FULLEST EXTENT PROVIDED BY APPLICABLE LAW, IN NO EVENT WILL AROVAST CORPORATION, ITS AFFILIATES, OR THEIR LICENSORS, SERVICE PROVIDERS, EMPLOYEES, AGENTS, OFFICERS, OR DIRECTORS BE LIABLE FOR:

(A) DAMAGES OF ANY KIND ARISING OUT OF OR IN CONNECTION WITH PRODUCTS PURCHASED FROM AROVAST CORPORATION IN EXCESS OF THE PURCHASE PRICE PAID BY THE PURCHASER FOR SUCH PRODUCTS, OR

(B) INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR PUNITIVE DAMAGES EVEN IF AROVAST CORPORATION OR ONE OF ITS SUPPLIERS HAS BEEN ADVISED OF THE POSSIBILITY OR LIKELIHOOD OF SUCH DAMAGES.

AND REGARDLESS OF WHETHER CAUSED BY TORT (INCLUDING NEGLIGENCE), BREACH OF CONTRACT, OR OTHERWISE. OUR LIABILITY SHALL UNDER NO CIRCUMSTANCES EXCEED THE ACTUAL AMOUNT PAID BY YOU FOR THE DEFECTIVE PRODUCT, NOR SHALL WE UNDER ANY CIRCUMSTANCES BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL OR PUNITIVE DAMAGES OR LOSSES, WHETHER

DIRECT OR INDIRECT.

EXCEPT AS COVERED BY THIS LIMITED PRODUCT WARRANTY STATEMENT, AROVAST CORPORATION SHALL NOT BE LIABLE FOR COSTS ASSOCIATED WITH THE REPLACEMENT OR REPAIR OF PRODUCTS PURCHASED FROM IT, INCLUDING, BUT NOT LIMITED TO, LABOR, INSTALLATION, OR OTHER COSTS INCURRED BY THE USER AND, IN PARTICULAR, ANY COSTS RELATING TO THE REMOVAL OR REPLACEMENT OF ANY PRODUCT.

Other Rights You May Have

SOME JURISDICTIONS DO NOT ALLOW FOR:

(1) EXCLUSION OF IMPLIED WARRANTIES;
(2) LIMITATION ON THE DURATION OF IMPLIED WARRANTIES; AND/OR (3) EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES; SO THE DISCLAIMERS

IN THIS POLICY MAY NOT APPLY TO YOU. IN THESE JURISDICTIONS YOU HAVE ONLY THE IMPLIED WARRANTIES THAT ARE EXPRESSLY REQUIRED TO BE PROVIDED IN ACCORDANCE WITH APPLICABLE LAW. THE LIMITATIONS OF WARRANTIES, LIABILITY, AND REMEDIES APPLY TO THE MAXIMUM EXTENT PERMITTED BY LAW.

ALTHOUGH THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, YOU MAY HAVE OTHER RIGHTS IN YOUR JURISDICTION. THIS STATEMENT OF LIMITED WARRANTY IS SUBJECT TO APPLICABLE LAWS THAT APPLY TO YOU AND THE PRODUCT. PLEASE REVIEW THE LAWS IN YOUR JURISDICTION TO UNDERSTAND YOUR RIGHTS FULLY.

Changes To This Policy

We may change the availability of this limited warranty at our discretion, but any changes will not be retroactive.

This warranty is made by:

AROFAST CORPORATION
1775 Flight Way, Suite 150
Tustin, CA 92782
USA

Customer Support

If you have any questions or concerns about your new product, please contact our helpful Customer Support Team.

Arovast Corporation

1775 Flight Way, Suite 150
Tustin, CA 92782
USA

Support Hours

Mon–Fri, 9:00 am–5:00 pm PST/PDT

URL: support.cosori.com

Toll-Free: 1-888-402-1684

**Please have your order invoice PDF or screenshot(s) ready before contacting Customer Support.*

This image shows a single sheet of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



Questions or Concerns?

support.cosori.com